

03—320 Mounting of crankshaft

Data

Crankshaft standard dimension and repair stages	Crankshaft bearing journal dia.	Fitted bearing Pertinent thickness of thrust washers	Width of journal	Crankpin dia.	Width of pin
Standard dimension	<u>69.96</u> 69.95	2.15	<u>34.00</u> 34.03	<u>51.96</u> 51.95	<u>32.00</u> 32.10
		2.20	<u>34.10</u> 34.13		
1st repair stage	<u>69.71</u> 69.70	2.25	<u>34.20</u> 34.23	<u>51.71</u> 51.70	to 32.30
2nd repair stage	<u>69.46</u> 69.45	or	or	<u>51.46</u> 51.45	
3rd repair stage	<u>69.21</u> 69.20	2.35	<u>34.40</u> 34.43	<u>51.21</u> 51.20	
4th repair stage	<u>68.96</u> 68.95	or 2.40	or <u>34.50</u> 34.53	<u>50.96</u> 50.95	






Basic bore and bearing play		Crankshaft bearing	Connecting rod bearing
Basic bore dia.		<u>74.50</u>	<u>55.60</u>
		74.52	55.62
Basic bore width on fitted bearing		<u>29.48</u>	—
		29.50	
Connecting rod width		—	<u>31.84</u>
			31.88
Permissible out-of-true of basic bore		0.01	
Permissible conicity of basic bore		0.01	
Bearing play radial	when new	0.031—0.073 ¹⁾	
	wear limit	0.08	
Bearing play axial	when new	0.10—0.25	0.12—0.26
	wear limit	0.30	0.50

¹⁾ For radial play try for mean value.

Bearing shells	Wall thickness crankshaft bearing	Wall thickness connecting rod bearing
Standard dimension	2.25	1.80
1st repair stage	2.37	1.92
2nd repair stage	2.50	2.05
3rd repair stage	2.62	2.17
4th repair stage	2.75	2.30

Tightening torques	Nm	
Crankshaft bearing bolts	90	
Connecting rod nuts	initial torque	40–50
	angle of rotation torque	90–100°
Bolt M 18 x 1.5 x 45 on crankshaft	270–330	
Necked-down screws for flywheel or driven plate	initial torque	30–40
	angle of rotation torque	90–100°

Special tools

Angle of rotation tool		116 589 01 13 00
Puller for balancing disc		116 589 10 33 00
Puller for crankshaft gear		615 589 01 33 00
Detent		110 589 00 40 00
Dial gauge holder for measuring end play		116 589 12 21 00

Note

Engine removed and disassembled.

Main oil ducts in crankcase open (also refer to 01—130).

Oil spray nozzles removed (18—040).

Oil ducts in cylinder crankcase and in crankshaft carefully cleaned.


Check crankshaft for cracks, dimensional stability and concentricity (03—318).

For durability, the 3rd crankshaft bearing (fitted bearing) has been provided with standard bearing shells and thrust washers.

The thrust washers absorb the axial forces of the crankshaft.

The thrust washers (32a and 32b) inserted in cylinder crankcase and in bearing cap on both sides are similar in design.

As a protection against distortion and to avoid assembly faults, the thrust washers in bearing cap are provided with two holding lugs each, with the lower lug placed out of center. In addition, all thrust washers are chamfered at one end.



32	Bearing shells	36	Cylindrical pin 10m 6 x 16
32a	Thrust washers in cylinder crankcase	37	Cylindrical pin 8m 6 x 16
32b	Thrust washers in bearing cap	39	Bearing cap
		41	Bolts M 12 x 75

When reconditioning crankshafts, regrind width of fitted bearing journals to one of the dimensions named in table (section "Data").

Coordinate thrust washers in accordance with pertinent journal widths (table).

Always install thrust washers of uniform thickness on both sides.

Regrinding of thrust washers is not permitted.

Spare part thrust washers are available in sets only. One set consists of an upper and a lower thrust washer (32a and 32b).

Thrust washer sets

Thickness in mm	Set part no.
2.15	617 586 19 03
2.20	617 586 20 03
2.25	617 586 21 09
2.35	617 586 22 03
2.40	617 586 31 03

Due to the higher combustion pressures the fatigue strength of connecting rod bearing shells has been improved by changing the composition of the material.

On these engines, do not install connecting rod bearing shells of engine 617.912.

To improve bearing shell seat in cylinder crankcase on engine 617.950, the standout of the bearing shells has been increased from 0.000–0.030 mm to 0.030–0.060 mm. On engines 617.951/952, from start of series.

Installation


Engine	Engine end no.
617.950	003 768
617.951/952	Start of series

Coordinating crankshaft bearings, installing crankshaft

1 Install crankshaft bearing cap. Pay attention to identification, 1 is at the front.


Do not interchange crankshaft bearing caps.

2 Tighten bolts to 90 Nm.





3 Measure basic bore in direction A, B and C on two levels (conicity).

If a basic bore exceeds the specified value or is conical, touch up bearing cap at its contact surface on a surface plate by max. 0.02 mm.




4 Insert crankshaft bearing shells and mount bearing cap. Tighten bolts to 90 Nm.






5 Measure bearing dia. and write down.




6 Measure crankshaft bearing journal, find crankshaft bearing radial play.

Note: The bearing play can be corrected by exchanging bearing shells, while trying for mean value of specified bearing play.

Crankshaft bearing shells without color coding are thicker than those with blue color coding, while taking into account that the wall thicknesses without color coding and those with color coding may overlap.




7 Measure width of fitted bearing journal and use pertinent thrust washers (refer to table, section "Data").



8 Renew rear crankshaft radial sealing ring (03-327).



9 Provide bearing shells, crankshaft and radial sealing ring with engine oil and insert crankshaft.



10 Provide thrust washers with engine oil and slip into grooves on fitted bearing (cylinder crankcase).

Attention!

The two oil grooves (arrows) in thrust washers should face crankshaft webs.




11 Mount fitted bearing cap.

Attention!


Provide thrust washers with engine oil and place into grooves on fitted bearing cap. The two oil grooves (arrows) in thrust washers should face crankshaft webs.

Hold both thrust washers in position and mount fitted bearing cap.




12 Mount crankshaft bearing cap.

13 Tighten all bearing caps to 90 Nm.



14 Measure crankshaft bearing end play.


15 Turn crankshaft manually and check for unobstructed running.



Coordinating connecting rod bearings and installing connecting rods


16 Check connecting rod bolts (03-310).

17 Recondition connecting rod and square (03-313).




18 Mount connecting rod bearing cap, while paying attention to identification. Lubricate connecting rod nuts and tighten to 40–50 Nm.

19 Measure basic bore in two directions. On a basic bore which exceeds the specified value or is conical, touch up bearing cap at its contact surface on a surface plate by max. 0.02 mm.




20 Insert connecting rod bearing shells, mount connecting rod bearing cap with bearing shells and tighten connecting rod nuts to 40–50 Nm.



21 Measure bearing dia. and write down.

22 Measure connecting rod bearing journal, find connecting rod bearing radial play.


Note: The bearing play can be corrected by exchanging bearing shells, while trying for mean value of specified bearing play. Connecting rod bearing shells without color coding are thicker than those with blue color coding, while taking into account that the wall thicknesses without color coding and those with color coding may overlap.




23 Mount piston on connecting rod (03-316).

24 Provide bearing shells, crankshaft, piston and cylinder walls with engine oil, install connecting rod with piston (03-316).

Pay attention to identification.



25 Tighten connecting rod nuts to 40–50 Nm initial torque and 90–100° angle of rotation torque.




26 Measure connecting rod bearing end play. Check connecting rod for easy operation in piston.


Attention!

Disassemble and clean oil pump and renew, if required. Renew oil pressure relief valve, disassemble oil filter and clean. Carefully clean air-oil cooler. Clean oil spray nozzles (18–040).

Install initial operation oil filter element. Change engine oil and oil filter element after 1000–1500 km.



Crankshaft and bearing shells



- | | | | |
|-----|---------------------------------|-----|---------------------------------------|
| 28 | Woodruff key | 36 | 6 Cylinder pins 10m 6 x 16 |
| 30 | Crankshaft | 37 | 6 Cylinder pins 8m 6 x 16 |
| 31a | Bearing shells upper halves | 38 | Camshaft bearing cap |
| 31b | Bearing shells lower halves | 38a | Camshaft bearing cap no. 1 |
| 32 | Bearing shells (fitted bearing) | 39 | Camshaft bearing cap (fitted bearing) |
| 32a | Thrust washers upper halves | 40 | Bolt M 8 x 25 |
| 32b | Thrust washers lower halves | 41 | 12 bolts M 12 x 75 |