





Fault readout via Diagnostic Trouble Code (DTC)

Special tools




Commercially available tools

Multimeter

e.g. Sun DMM-5

Diagnostic program

A diagnostic program is integrated into the ASD control module (N30/2) for monitoring the electronic circuit. Upon recognition of a malfunction the ASD Malfunction Indicator Lamp (MIL) (A1e24) illuminates while riding. The fault stored can be read out as a Diagnostic Trouble Code (DTC) with the ASD MIL (A1e24) or the impulse counter scan tool. The number of flashes indicates which electric circuit is defective (see table: "Diagnostic Trouble Code").



- a Line with plug
- A1e24 Malfunction Indicator Lamp, ASD/4MATIC
- N30/2 ASD control module
- X11/4 Data link connector (DTC readout)

P35-0129-15


35-516 Testing ASD electrical system - DTC readout

Output of diagnostic trouble code via ASD Malfunction Indicator Lamp (MIL)

- 1 Allow engine to run.
- 2 Jumper sockets 1 and 5 in data link connector (X11/4) with plug from 201 589 00 99 00 (a) for approx. 1 second.

Note


After disconnecting the MIL extinguishes for approx. 2 seconds (a) and then starts flashing regularly with an interval of approx. 1 second (b).



P35-0181-13

- 3 Read off diagnostic trouble code (b) on MIL. After output of the codes the MIL illuminates continuously.

Arrangement of flash impulses
a Pause approx. 2 seconds
b Number of diagnostic trouble code e.g. "4"



P35-0130-11

Cancelling the diagnostic trouble code

After eliminating the malfunction, the stored diagnostic trouble code must then be erased.

- 4 Allow engine to run.
- 5 Perform items 2 and 3 again.

Note

The fault must be read out again at least once immediately before deleting.

- 6 Jumper sockets 1 and 5 in test coupling for at least 10 seconds. The MIL extinguishes indicating that the stored code has been deleted correctly.


Output of diagnostic trouble code via impulse counter scan tool

- 1 Connect impulse counter scan tool 124 589 19 21 00.
- 2 Allow engine to run.
- 3 Press "Start" key for 1 second to read off malfunction diagnostic trouble code, 10 seconds to delete.

Note

The malfunction must be read out again at least once immediately before deleting.

35-516 Testing ASD electrical system - DTC readout



P35-0132-57


Connection schematic, impulse counter scan tool

- 013 Impulse counter scan tool 124 589 19 21 00
- X4/10 Terminal block (circuit 30/circuit 61 battery) (3-pole)
- X11/4 Data link connector (DTC readout)

35-516 Testing ASD electrical system – DTC readout

Diagnostic Trouble Codes (DTCs)

Number of flash pulses	Malfunction
1	No malfunction
2	ASD control module (N30/2) defective
3	Brake light switch (S9/1); ASD switching function defective – rest circuit
4	Speed impulse, front left missing; contact interruption
5	Speed impulse, front right missing; contact interruption
6	Speed impulse, rear missing; contact interruption
7	All three speed impulses missing
8	ASD valve (Y38), relay overvoltage protection (K1/2) or brake light switch (S9/1); switching function brake light defective – operating circuit



P35-0133-57A

Connection schematic, socket box

- 01 Coupling, ASD control module
- 02 Test cable 124 589 28 63 00
- 03 Multimeter
- 04 Socket box 124 589 00 21 00

35-516 Testing ASD electrical system – DTC readout

Prerequisites for testing

- Check fuse 7 terminal 15 in fuse box.
- Check fuses, relay, overvoltage protection.
- Check battery voltage (11-14 V), charge battery if required.
- Disconnect ASD control module (N30/2).
- Connect test cable 124 589 28 63 00 and socket box 124 589 00 21 00 to cable harness.

Test step/DTC 1





Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
-	-	-	-	No fault in system

Test step/DTC 2

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
-	-	-	-	Exchange ASD control module (N30/2) (35-512)

35-516 Testing ASD electrical system – DTC readout

Test step/DTC 3

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check brake light switch (S9/1) rest circuit		Ignition: ON Ignition: OFF	> 11 V approx. 0 V	Exchange brake light switch (S9/1)
		Ignition: OFF Brake actuated	$\infty \Omega$	
		Ignition: ON	> 11 V	
		Ignition: ON	approx. 0 V	







35-516 Testing ASD electrical system – DTC readout

Test step/DTC 4

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check speed sensor, front left wheel (L6/1)		Ignition: ON Turn wheel 1/s	approx. 4 V	Line from ASD control module (N30/2) socket 9 to battery ground (W10) interrupted. Distance between speed sensor-rotor too great. Speed sensor dirty.
		Ignition: OFF	< 1 Ω	Line from ASD control module (N30/2) socket 5 to ABS control module (N30) socket 17 interrupted.
		Ignition: OFF	< 1 Ω	Line from ABS control module (N30/2) socket 6 to plug connector for speed sensor, left front wheel (L6/1x1) interrupted.
		Ignition: OFF	< 1 Ω	Line from ABS control module socket 4 to plug connector, speed sensor, left front wheel (L6/1x1) interrupted.
		Ignition: OFF	0.85–2.3 kΩ	Speed sensor (L6/1) interrupted.
		Ignition: OFF	∞ Ω	Speed sensor (L6/1) short-circuited to ground.

35-516 Testing ASD electrical system – DTC readout

Test step/DTC 5

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check speed sensor, front right wheel (L6/2)		Ignition: ON Turn wheel 1/s	approx. 4 V	Line from ASD control module (N30/2) socket 9 to battery ground (W10) interrupted. Distance between speed sensor-rotor too great. Speed sensor dirty.
		Ignition: OFF	< 1 Ω	Line from ASD control module (N30/2) socket 3 to ABS control module (N30) socket 11 interrupted.
		Ignition: OFF	< 1 Ω	Line from ABS control module socket 23 to plug connector, speed sensor, right front wheel (L6/2x1) interrupted.
		Ignition: OFF	< 1 Ω	Line from ABS control module socket 21 to plug connector for speed sensor, right front wheel (L6/2x1) interrupted.
		Ignition: OFF	0.85–2.3 kΩ	Speed sensor (L6/2) interrupted.
		Ignition: OFF	∞ Ω	Speed sensor (L6/2) short-circuited to ground.

35-516 Testing ASD electrical system - DTC readout

Test step/DTC 6

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check speed sensor, rear axle (L6)	 9 — $\leftarrow \text{V} \rightarrow$ — 1	Ignition: ON Shift to neutral, turn wheel 1/s	approx. 4 V	Line from ASD control module (N30/2) socket 9 to battery ground (W10) interrupted. Interval between speed sensor-rotor too great. Speed sensor dirty.
	 N30 30 — $\leftarrow \Omega \rightarrow$ — N30/2 1	Ignition: OFF	< 1 Ω	Line from ASD control module (N30/2) socket 1 to ABS control module (N30) socket 30 interrupted.
	 N30 7 — $\leftarrow \Omega \rightarrow$ — L6x1 1	Ignition: OFF	< 1 Ω	Line from ABS control module (N30) to first plug connector (X47) or from plug connector (X47) to second plug connector (L6x1) interrupted.
	 N30 9 — $\leftarrow \Omega \rightarrow$ — L6x1 2	Ignition: OFF	< 1 Ω	Line from ABS control module (N30) to first plug connector (X47) or from plug connector (X47) to second plug connector (L6x1) interrupted.
	 L6x1 1 — $\leftarrow \Omega \rightarrow$ — L6x1 2	Ignition: OFF	0.85–2.3 k Ω	Speed sensor (L6) interrupted.
	 L6x1 1 — $\leftarrow \Omega \rightarrow$ — \perp	Ignition: OFF	$\infty \Omega$	Speed sensor (L6) short-circuited to ground.

35-516 Testing ASD electrical system – DTC readout

Test step/DTC 7

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check line continuity from ASD control module (N30/2) to battery ground (W10) (all three speed impulses missing)		Ignition: OFF	< 1 Ω	Line from socket 8 and socket 9 to battery ground (W10) interrupted. ABS control module defective or wrong control module installed.

Test step/DTC 8

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check brake light switch, ASD (S9/1) operating circuit		Ignition: ON Brakes actuated	approx. 0 V > 11 V	Line from socket 11 ASD control module (N30/2) to brake light switch (S9/1) via line connector (X21/2) interrupted. Exchange brake light switch (S9/1).
		Ignition: OFF Brake not actuated	$\infty \Omega$	
Check brake light switch (S9/1) rest circuit		Ignition: ON Brake actuated	> 11 V approx. 0 V	Exchange brake light switch (S9/1). Exchange brake light switch (S9/1).
		Ignition: OFF Brake not actuated	< 1 Ω	
Check ASD valve (Y38) function		Ignition: ON	ASD valve switches	Line from socket 10 on ASD control module (N30/2) via plug connector X62/5 and Y38x1 to ASD valve (Y38) interrupted.

35-516 Testing ASD electrical system - DTC readout

Test step/DTC 8 (continued)

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check ASD valve (Y38) function	<p>1 — Y38 — 2</p>	Ignition: OFF Plug disconnected	5.7-6.1 Ω or ∞ Ω	Value for continuity test 5.6-6.1 Ω. For ground short test ∞ Ω. If these values are not measured, ASD valve (Y38) is defective.
	<p>Y38x1 — S9/1 — 3</p>	Ignition: OFF	< 1 Ω	Line from plug connector, ASD valve (Y38x1) via plug connectors (X62/5) to brake light switch (S9/1) interrupted.
	<p>K1/2 — S9/1 — 4</p>	Ignition: OFF	< 1 Ω	Line from brake light switch (S9/1) to relay, overvoltage protection (K1/2) terminal 87L interrupted.
	<p>⊥ — K1/2 — 1</p>	Ignition: ON	> 11 V	Line between battery and relay, overvoltage protection (K1/2) via line connector (X4/10) interrupted.
	<p>⊥ — K1/2 — 3</p>	Ignition: ON	> 11 V	Line between ignition lock and relay, overvoltage protection (K1/2) interrupted.
	<p>K1/2 — W10</p>	Ignition: ON	> 11 V	Line between battery ground (W10) and relay, overvoltage protection (K1/2) interrupted.
	<p>⊥ — S9/1 — 4</p>	Ignition: ON Overvoltage protection (K1/2) connected	> 11 V	If the value is not measured, relay, overvoltage protection (K1/2) defective.

35-516 Testing ASD electrical system – DTC readout

Fault recognition via warning lamp and MIL, which cannot be read out via stored diagnostic trouble code

Complaint-related troubleshooting chart

Complaint	Possible cause	Repair instructions
Warning lamp (A1e25) does not illuminate, MIL (A1e24) illuminates with ignition: ON	Line between ASD control module (N30/2) and warning lamp (A1e25), bulb, electronic stage of warning lamp, ASD control module (N30/2) defective.	Test step 1
Warning lamp (A1e25) does not change brightness when parking lights and low-beam headlights are switched on. Ignition: ON	Electronic stage of warning lamp (A1e25) defective.	Test step 2
MIL (A1e24) does not illuminate, warning lamp (A1e25) illuminates. Ignition: ON	Line between ASD control module (N30/2) and MIL (A1e24), bulb, ASD control module defective.	Test step 3
Warning lamp (A1e25) and MIL (A1e24) illuminate continuously – engine running	Line between ASD control module (N30/2) and terminal 61e interrupted. No voltage at terminal 61e, ASD control module defective.	Test step 4 If voltage is not present at terminal 61e, this can also be seen on the charging indicator therefore check line or alternator, regulator. Replace ASD control module (N30/2).
Warning lamp (A1e25) and MIL (A1e24) do not illuminate. Ignition: ON	Lines interrupted. ASD control module (N30/2) or relay, overvoltage protection (K1/2) defective.	Test step 5

35-516 Testing ASD electrical system – DTC readout

Test step 1




Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check warning lamp (A1e25) for proper function		Ignition: OFF	< 1 Ω	Line between socket 4 on ASD control module (N30/2) to electronic stage or warning lamp (A1e25) interrupted. Bulb defective. Electronic stage of warning lamp defective.

Test step 2

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check warning lamp (A1e25) for brightness adjustment		Ignition: OFF	< 1 Ω	Line from rotary light switch (S1) to warning lamp (A1e25) interrupted. Replace complete electronic stage of warning lamp.






35-516 Testing ASD electrical system – DTC readout

Test step 3

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check MIL (A1e24) for function		Ignition: ON	Control light illuminates	Line from socket 8 to battery ground (W10) interrupted.
		Ignition: OFF	< 1 Ω	Line from socket 2 on ASD control module (N30/2) to plug connector on MIL (A1e24) interrupted.
		Ignition: ON	> 11 V	Line from coupling, warning lamp (A1e25/2) to soldered connection, MIL (A1e24) interrupted. Bulb defective.


35-516 Testing ASD electrical system - DTC readout

Test step 4

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Warning lamp (A1e25) and MIL (A1e24) illuminate continuously - engine running	W10  N30/2 — 8	Ignition: OFF	< 1 Ω	Line from socket 8, ASD control module (N30/2) to battery ground (W10) interrupted.
	K1/2  N30/2 8 — 12	Ignition: ON	> 11 V	Only possible on 1st version up to approx. 03/89: line from socket 12, ASD control module (N30/2) to relay, overvoltage protection (K1/2) interrupted.
	N30/2  K1/2 12 — 8	Ignition: OFF	< 1 Ω	Only possible on 1st version up to approx. 03/89: line from socket 12, ASD control module (N30/2) to relay, overvoltage protection (K1/2) interrupted.
	—  K1/2 — 8	Ignition: ON	> 11 V	Only required on 1st version up to approx. 03/89. Power discontinuity in relay, overvoltage protection (K1/2) replace. Fuse defective.
	—  K1/2 — 7	Ignition: ON	> 11 V	2nd version from approx. 04/89 power discontinuity in relay, overvoltage protection (K1/2) - replace. Fuse defective. Note If power is not present at terminal 7 (K1/2), the ASD system does not function at all.





35-516 Testing ASD electrical system – DTC readout

Test step 4 (continued)

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Check terminal D + alternator - voltage at terminal 61e		Engine: OFF Start engine	0 V > 12.5 V	Line from socket 13 on ASD control module (N30/2) to line connector (X35) 1st version and (X4/10) 2nd version terminal 61e interrupted. If the charge indicator light illuminates simultaneously, then check line, alternator and regulator. Replace ASD control module.










35-516 Testing ASD electrical system – DTC readout

Test step 5

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
Warning lamp (A1e25) and MIL (A1e24) do not illuminate Ignition: ON		Ignition: ON	> 11 V	Line from socket 14 on ASD control module (N30/2) to relay, overvoltage protection (K1/2) socket 7 interrupted.
		Ignition: ON	> 11 V	Line between battery via line connector X35 1st version and X4/10 2nd version to relay overvoltage protection (K1/2) interrupted.
		Ignition: ON	> 11 V	Line from ignition switch via plug connector, engine harness (a) to relay, overvoltage protection (K1/2) interrupted.
		Ignition: ON	> 11 V	Discontinuity in relay – overvoltage protection (K1/2) replace. Fuse in relay – overvoltage protection defective

35-516 Testing ASD electrical system - DTC readout

Test step 5 (continued)

Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
	W10  N30/2 	Ignition: ON	Warning lamp illuminates	Line from socket 8 on ASD control module (N30/2) to battery ground (W10) interrupted.
	N30/2  A1e25 4 	Ignition: OFF	< 1 Ω	Line from socket 4, ASD control module to socket 1, warning lamp interrupted.
	W1  A1e25 	Ignition: OFF	< 1 Ω	Line from socket 4 on warning lamp (A1e25) to ground (W1) interrupted.
	  A1e25 	Ignition: ON	> 11 V	Line from fuse box (fuse 7, socket 15) to warning lamp (A1e25) interrupted. Exchange electronic stage.