



32-660 R and R level controller connecting link

Position of connecting rod on lever of level controller

Model	Position of connecting rod on lever of level controller	
107.022 126.02	Bore a	Version up to 08/85
107.023 126.032		Version starting 09/85
107.025 126.033		
114 126.034		
115 126.043		
116.02 126.046		
116.032 ¹⁾ 126.125 ²⁾		
116.033 ¹⁾		
107.024 126.036	Bore b	
107.026 126.037		
116.032 126.039		
116.033 126.044		
123 126.045		



¹⁾ Vehicles in (J) version only.

²⁾ (USA)

a, b Bores for ball joint of connecting rod
 c Locating bores in lever and in housing in center position of control shaft for locating pin 4.0 mm dia.

Lubricant for steel-mounted ball joints of connecting rod (vehicles up to March 1971)¹⁾

Grease type Longterm lubricating grease (refer to Specifications for Service Products page 266.2)

¹⁾ Ball joints with plastic bearings (standard starting April 1971) require no service.

Note

After exchanging connecting rod, readjust vehicle level on rear axle again under load (40-310).


Removal

1 Unscrew hex. nuts of connecting rod (7) on lever of level controller and on lever of torsion bar.

If required, hold ball pin joints in plastic bearings with open-end wrench 10 mm or ball pin of steel joints with an angle screwdriver.


Model 116
Level controller on diagonal swing axle
without starting torque compensation

- | | |
|------------------------------|--|
| 3 Level controller | B1 Pressure line pressure oil pump – level controller |
| 3a Lever on level controller | B2 Pressure line level controller – pressure reservoir |
| 6 Lever on torsion bar | C Return flow line level controller – fluid reservoir |
| 7 Connecting rod | |
| 8 Bracket | |
| 10 Torsion bar | |




Model 116
Level controller on diagonal swing axle
with starting torque compensation

- | | |
|------------------------------|--|
| 3 Level controller | B1 Pressure line pressure oil pump – level controller |
| 3a Lever on level controller | B2 Pressure line level controller – pressure reservoir |
| 6 Lever on torsion bar | C Return flow line level controller – fluid reservoir |
| 7 Connecting rod | |
| 8 Bracket | |
| 10 Torsion bar | |




Model 123
Level controller on diagonal swing axle
without starting torque compensation
1st version up to February 1977

- | | |
|------------------------------|--|
| 3 Level controller | B1 Pressure line pressure oil pump – level controller |
| 3a Lever on level controller | B2 Pressure line level controller – pressure reservoir |
| 6 Lever on torsion bar | C Return flow line level controller – fluid reservoir |
| 7 Connecting rod | |
| 8 Bracket | |
| 10 Torsion bar | |



Model 123
Level controller on diagonal swing axle
without starting torque compensation
2nd version starting March 1977


- | | |
|------------------------------|--|
| 3 Level controller | B1 Pressure line pressure oil pump – level controller |
| 3a Lever on level controller | B2 Pressure line level controller – pressure reservoir |
| 3l Connection | C Return line level controller – fluid reservoir |
| 6 Lever on torsion bar | |
| 7 Connecting rod | |
| 8 Bracket | |
| 10 Torsion bar | |
| 11a Bleed screw | |



32-660 R and R level controller connecting link

Model 126
Level controller on diagonal swing axle
without starting torque compensation


- | | | | |
|----|------------------------------------|-----|---|
| 3 | Level controller | 11a | Bleed screw |
| 3a | Lever on level controller | B1 | Pressure line pressure oil pump - level controller |
| 3l | Connection fore pressure line (B1) | B2 | Pressure line level controller - pressure reservoir |
| 3m | Connection for return line (C) | C | Return line level controller - fluid reservoir |
| 6 | Lever on torsion bar | | |
| 7 | Connecting rod | | |
| 8 | Bracket | | |
| 10 | Torsion bar | | |



132-17879

Model 126 version starting 9/85

- | | |
|----|---------------------------|
| 3 | Level controller |
| 3a | Lever on level controller |
| 3p | Bleed screw |




132-31543

2 Check ball joints of connecting rod for easy operation and wear.

3 On 1st version with steel joints (standard up to March 1971) remove respective locking clip (7b) and pull off ball pin. Provide ball sockets with grease. Replace damaged sealing washers (7c) or worn-out ball joints.

Connecting rod with steel joints
1st version up to March 1971

- | | | | |
|----|----------------|----|-------------|
| 7a | Ball joint | 7d | Ball pin |
| 7b | Locking clip | 7e | Ball socket |
| 7c | Sealing washer | | |




R 32/6513/1

Attention!

Do not pull ball pin of plastic-mounted ball joints out of ball socket.


Connecting rod with ball joint
mounted on plastic bearings

2nd version starting April 19



R 32/7280

32-660 R and R level controller link



Connecting rod with ball joints
mounted on plastic bearings
3rd version starting March 1979


132-19672

Installation

4 Attach connecting rod lever to lever of level controller and to lever of torsion bar. Make sure that lever (6) of torsion bar is in alignment with connecting rod.


Model 107, 114, 115
Layout of level controller

- 3 Level controller
- 3a Lever on level controller
- 6 Lever on torsion bar
- 7 Connecting rod
- 7a Ball joint
- 7b Locking clip
- 7c Sealing washer
- 8 Bracket
- 10 Torsion bar
- B1 Pressure line pressure oil pump – level controller
- B2 Pressure line level controller – pressure reservoir
- C Return flow line level controller – fluid reservoir



Model 123
Layout of level controller

- 3 Level controller
- 3a Lever on level controller
- 3l Connection
- 6 Lever on torsion bar
- 7 Connecting rod
- 8 Bracket
- 10 Torsion bar
- 11a Bleed screw
- B1 Pressure line pressure oil pump – level controller
- B2 Pressure line level controller – pressure reservoir
- C Return line level controller – fluid reservoir




32-660 R and R level controller connecting link

Model 126

Layout of level controller

- 3 Level controller
- 3a Lever on level controller
- 3l Connection for pressure line (B1)
- 3m Connection for return line (C)
- 6 Lever on torsion bar
- 7 Connecting rod
- 8 Bracket
- 10 Torsion bar
- 11a Bleed screw
- B1 Pressure line pressure oil pump – level controller
- B2 Pressure line level controller – pressure reservoir
- C Return line level controller – fluid reservoir




5 Check fastening clip (6a) for tight seat on torsion bar.

Model 126 version starting 9/85

Layout of level controller

- 3 Level controller
- 3a Lever on level controller
- 6 Lever on torsion bar
- 7 Connecting rod
- 8 Bracket
- 10 Torsion bar
- 11a Bleed screw
- B1 Pressure line pressure oil pump – level controller
- B2 Pressure line level controller – pressure reservoir
- C Return line level controller – fluid reservoir




Version up to 8/85

Attention!

Starting December 1972 a level controller with a larger lever has been installed. This lever has two bores for attaching connecting rod. The bores for the connecting rod for the various models are shown in table.


- „a“ = Bore for connecting rod of diagonal swing axle without starting torque compensation (not model 123)
- „b“ = Bore for connecting rod of diagonal swing axle with starting torque compensation (and model 123)



32-660 R and R level controller link

Version starting 9/85

- „a“ = Bore for connecting rod of diagonal swing axles **without** starting torque compensation
- „b“ = Bore for connecting rod of diagonal swing axles **with** starting torque compensation
- „c“ = Locating bores in lever and in housing in center position of controller control shaft for pin dia. 4 mm



6 Checking and adjusting vehicle level on rear axle under load (40-310).