PIN 21 Roadster Soft Top (129)

- 1 No Fault
- 2 Limit switch, left locked, soft top storage compartement cover
- 3 Limit switch, right locked, soft top storage compartement cover
- 4 Limit switch, left closed, soft top storage compartment cover
- 5 Limit switch, right closed, soft top storage compartment cover
- 6 Limit switch, left locked, soft top fabric bow
- 7 Limit switch, right locked, soft top fabric bow
- 8 Limit switch, left closed, soft top fabric bow
- 9 Limit switch, right closed, soft top fabric bow
- 10 Limit switch, left front locked, soft top
- 11 Limit switch, right front locked, soft top
- 12 Limit switch soft top sotrage compartment cover open
- 13 Limit switch soft top fabric bow raised
- 14 Limit switch soft top down (in storage compartment)
- 15 Limit switch soft top up (secondary closing speed)
- 16 Limit switch roll bar retracted
- 17 Limit switch left side window down Circuit in power soft top control module solenoid valve, roll bar retracted
- 18 Limit switch right side window down Circuit hydraulic unit, circuit solenoid valve, roll bar retracted
- 19 Axle vehicle speed signal illogical Circuit in power soft top control module, solenoid valve, roll bar extended
- 20 Hartop installation recongition Circuit solenoid valve, roll bar extended
- 21 Power soft top switch Circuit in power soft top control module, Power windows
- 22 Roll bar switch
- 23 Roll bar control module
- 24 Roll bar crash deployment
- 25 Limit switch signals illogcial
- 26 Operation time exceeded
- 27 Insufficient voltage
- 28 No speedometer signal
- 29 No axle vehicle wheel speed sensor signal
- 30 Soft top operation blocked