

PIN 6**ABS**

- 1 No fault
- 2 Left front axle vehicle speed sensor, open circuit
- 3 Right front axle vehicle speed sensor, open circuit
- 4 Rear axle vehicle speed sensor, open circuit
- 6 Left front axle solenoid valve
- 7 Right front axle solenoid valve
- 8 Rear axle solenoid valve
- 10 Return pump or return pump relay
- 11 Solenoid valve relay
- 12 Master cylinder switchover valve
- 13 Brake lamp switch
- 14 Lateral acceleration sensor
- 15 ABS Control Module
- 16 Vehicle speed sensors, implausible signal
- 17 Solenoid valve relay
- 25 Left front axle vehicle speed sensor, implausible signal
- 26 Right front axle vehicle speed sensor, implausible signal
- 27 Rear axle vehicle speed sensor, implausible signal
- 29 Lateral acceleration sensor, implausible signal