

- PIN 3 CIS-E 420SEL (8 PIN DTC)
- 1 No fault
 - 2 Throttle valve switch, full throttle contact
 - 3 Coolant temperature sensor
 - 4 Air flow sensor potentiometer
 - 5 Oxygen sensor
 - 6 N/A
 - 7 TD signal
 - 8 Altitude correction sensor
 - 9 Electrohydraulic actuator
 - 10 Throttle valve switch, idle contact
 - 11 N/A
 - 12 Exhaust gas recirculation (EGR)