

PIN 5 4MATIC System w124 (300e) - **ENGINE MUST BE AT IDLE**

- 1 No fault
- 2 4MATIC control module
- 3 Stop lamp switch
- 4 Left front axle vehicle speed sensor
- 5 Right front axle vehicle speed sensor
- 6 Rear axle VSS
- 7 Axle VSS sensors or ABS control module
- 8 Overvoltage protection relay module, or front axle drivetrain valve, or central differential lock valve
- 9 Overvoltage protection relay module, central differential lock valve, or rear axle differential lock valve or stop lamp switch
- 10 Overvoltage protection relay module, or rear axle differential lock valve, or stop lamp switch
- 11 Overvoltage protection relay module, or steering angle sensor