



Roll Bar Warning Lamp

The roll bar warning lamp is located next to the roll bar switch in the center console.

With the key in steering lock position 2, the roll bar warning lamp comes on and should go out when the engine is running.

If the roll bar warning lamp and the indicator lamps in the roll bar switches stay on continuously, then a malfunction has been detected.

In this case, drive only with the roll bar raised until the problem has been corrected. Raise the roll bar by pressing the upper half of the roll bar switch. The indicator lamps in the switch will go out, however, the warning lamp in the instrument cluster will stay on.

Have the system checked at your authorized Mercedes-Benz dealer as soon as possible.