

Cargo Compartment below Cargo Space Floor

An additional cargo compartment below the cargo space floor is available if the rear-facing bench seat is not installed.

To open, press the grip and lift up cover.

The rear cargo compartment cover can be locked with the master key.

Retractable Luggage Cover and Partition Net

The twin-reel roller blind comprises a luggage cover and a partition net. It is mounted on the backrest of the rear seat and can also be used with the backrest folded down.

Luggage cover:

Pull out lower blind, draw it over the luggage and engage into eyelets on the tailgate. When the tailgate is opened the blind is lifted up with it so that it need not be retracted for loading or unloading the vehicle.

To retract the lower blind, disengage it from eyelets on tailgate and slowly guide it into its receptacle.

Partition net:

Pull out upper blind (safety net) and engage into eyelets on the roof. This is a particularly important safety factor when the vehicle is loaded higher than the top of the rear seat backrest.

Warning!

To help avoid personal injury during a collision or sudden maneuver, always use partition net when transporting cargo.

Removal of twin-reel roller blind:

Fold backrests forward, push cover mechanism to the left and remove.