



P54-0010-B34B

Instrument Cluster

- | | |
|--|--|
| <ul style="list-style-type: none"> 1 Coolant temperature gauge. See Index 2 Fuel gauge with reserve warning lamp (yellow). See Index 3 Engine oil pressure gauge (bar). See Index 4 Turn signal indicator lamp, left (green) 5 Knob for instrument lamps and trip odometer
Rotate knob: to vary intensity of instrument lamps
Depress knob: to reset trip odometer 6 Speedometer 7 ASR warning lamp (yellow). See Index | <ul style="list-style-type: none"> 8 Main odometer 9 Trip odometer 10 Outside temperature indicator. See Index 11 Turn signal indicator lamp, right (green) 12 Knob for clock adjustment
(press in and rotate for adjustments) 13 Electric clock 14 Tachometer 15 Red marking on tachometer:
Excessive engine speed. See Index |
|--|--|