
Inside and Exterior Rear View Mirrors

Inside Rear View Mirror

Use your inside mirror to determine the size and distance of objects seen in the passenger side convex mirror.



Antiglare Night Position

Tilt the mirror to the antiglare night position using the lever at its lower edge.