


B. Brake lamp

- | | |
|------------------------|---|
| Brake lamp (3) | pull out from the front, push in to the rear. |
| Parcel shelf (4) | remove, reinstall (68-0458). |
| Lock washers (5) | remove, press on. |
| Console (6) | remove, install. |

C. Wiring diagrams



- | | |
|-----|---|
| E21 | 3rd brake lamp |
| N7 | Lamp control unit |
| W6 | Ground, trunk wheel arch, left |
| X18 | Connector interior/tail lamp wiring harness,
12-pole |