


## 68-105 R and R speaker cover

---


### Removal

---

- 1 Unscrew screws on cover.



- 2 Pull cover to the rear and disconnect.



### Installation

---

- 3 For installation proceed vice versa.