

68-120 R and R glove box cover


Removal

1 Remove cover under instrument panel (68-150).

2 Unscrew screws on glove box cover hinge.



3 Swivel glove box cover in upward direction and move outwards with both stop brackets.



Installation

4 For installation proceed vice versa.