

72-102 R and R window frame inner trim

Note

The material of the window frame linings has been changed from plastic sheeting to a sprayed-on rigidly contoured version.

1. version up to 05/83
2. version starting 06/83

Spare part linings are now available in modified version only. This version is no longer glued-on.

Removal and installation

- 1 Remove door lining (72-100 or 72-101).
- 2 Remove inside sealing strip (72-160).
- 3 Partially remove flexible window run channel (72-198).
- 4 Partially remove sealing frame on driver's door or rear compartment door (72-220).
- 5 Remove external rear view mirror (88-900).
- 6 Partially remove stationary window on rear compartment door (72-197).
- 7 Loosen lining 1st version on glued spots and remove.
Remove lining 2nd version from window frame.
- 8 For installation proceed vice versa.