

46-700 Power steering pump identification

A. Power steering pump (VT 49 and ZL 49)

Installed in model	Opening pressure, safety valve (bar gauge pressure)	Color code, identification plate
126.032/033/035 126.037/039 126.043/044/045 126.120/125	82 ± 5	blue

ZL = Power steering pump from the company "Zahnradfabrik Friedrichshafen".
VT = Power steering pump from the company "Vickers".

B. Power steering pump (VT 161 and ZL 161)

Installed in model	Opening pressure, safety valve (bar gauge pressure)	Color code, identification plate
126.024/025 126.134/135	82 ± 5	blue

ZL = Power steering pump from the company "Zahnradfabrik Friedrichshafen".
VT = Power steering pump from the company "Vickers".

C. Tandem pump VTP 162 (for level control, ASD)

Installed in model	Opening pressure, safety valve (bar gauge pressure) Servo circuit	Opening pressure, safety valve (bar gauge pressure) Level circuit	Color code, identification plate
126.020/024/025 126.134/135	82 ± 5	125 ± 5	blue

VTP = Power steering pump from the company "Vickers".