


80-112 Checking electrical function of actuator

Preliminary work:
Checking electrical function of the central locking system
(80-104)



P80-0106-57

Test preparation	Items 1-3.
Locking function of the actuator	Check.
Opening function of the actuator	Check.
Voltage supply to the actuator	Check.


Commercially available tool

Digital multimeter	e.g. SUN, DMM-5
--------------------	-----------------

80-112 Checking electrical function of actuator




Test preparation

- 1 Remove actuator (80-215).
- 2 Disconnect electrical cable harness and pneumatic pipe.
- 3 Slide sliding sleeve (a) over the control rod attachment (b) while pushing the sliding sleeve lock (arrow) if required.



P80-2118-13

Test



80-112 Checking electrical function of actuator

