

All cabriolet and coupes

- With engine idling and doors open, check that backrests are free to move forward.
- Close doors. Backrests should now be locked.
- With doors closed, backrest lock should release when pushing button (arrow) on side of backrest.

