

Instruments and Controls

For more detailed descriptions see specified pages.

- 1 Air volume control for side air outlets (page 22)
- 2 Side air outlets (page 22)
- 3 Adjustable air outlets (page 22)
- 4 Parking brake release (page 58)
- 5 Hood lock release (page 74, 75)
- 6 Parking brake pedal (page 58)
- 7 Combination switch (page 50)
- 8 Exterior lamp switch (page 49)
- 9 Cruise control (page 62)
- 10 Instrument cluster (page 12)
- 11 Horn, driver airbag (page 43)
- 12 Steering lock with ignition/starter switch (page 48)
- 13 Air volume control lever for center and side air outlets (page 22)
- 14 Rear window defroster switch (page 54)
- 15 Air recirculation switch (page 22)
- 16 Hazard warning flasher switch
- 17 Snow chain switch (page 69)
- 18 Rear passenger compartment lamp switch (page 55)
- 19 Automatic climate control (page 22)
- 20 Radio
- 21 Ashtray with lighter (pages 53, 99)
- 22 Left front seat heater switch (page 34)
- 23 Fanfare horn control switch
- 24 Switch for rear window sun shade
- 25 Right front seat heater switch (page 34)
- 26 Left power window switch group (page 56)
- 27 Adjusting switch for exterior mirror on front passenger side (page 52)
- 28 Loudspeaker front to rear fader control
- 29 Right power window switch group (page 56)
- 30 Front passenger airbag (page 43)

