




P54-0037-B34

Instrument Cluster

- 1 Knob for instrument lamps and trip odometer.
Rotate knob: To vary intensity of instrument lamps.
Depress knob: To reset trip odometer.
- 2 Fuel economy gauge. See page 63
- 3 Coolant temperature gauge. See page 65
- 4 Fuel gauge with reserve warning lamp (yellow). See page 65
- 5 Oil pressure gauge (bar). See page 64
- 6 Turn signal indicator lamp, left (green)
- 7 Speedometer
- 8 ASR function indicator lamp (yellow).
See page 69.
- 9 Main odometer
- 10 Trip odometer
- 11 Outside temperature indicator. See page 66
- 12 Turn signal indicator lamp, right (green)
- 13 Electric clock
- 14 Tachometer
- 15 Red marking on tachometer:
Excessive engine speed
- 16 Knob for clock adjustment
(press in and rotate for adjustments)