

124.27-2.00	Transmission Oil Cooling	As of M.Y.1993	Page 1 of 1
-------------	--------------------------	----------------	-------------

A27	Transmission oil cooling fan	3M
A27m1	Cooling fan motor	3M
A27s1	100 °C temperature switch	2M
A27x1	Transmission oil cooling fan connector	2I
F1	Fuse and relay box	
F1-12	Fuse 12, terminal 15	2L
K25	Transmission cooling fan relay module	2A
W16/2	Ground (component compartment - generator/battery harness noise suppressor)	
	Grounds not indicated, components are connected on engine block or bodywork	
X12/1	Terminal block (terminal 15 unfused)	1F
	Cross Section of Wire may differ from Values shown in Wiring Diagram. Changes in Cross Section of Wire will be shown framed.	
	Explanations and Notes of Wiring Diagram see Section 00-A Locations/Connections/Overview see Section 00-B/00-C	

